

取扱説明書

一、注意事項

1.1 使用する前に、最低2時間以上充電してください。

1.2 パスワードについて

パスワードにより他の人が勝手にウォッチを使用する事ができません。

初期パスワード:1122

二、機能紹介

電源ボタン：長押しと、電源 ON OR 電源 OFF

待受画面で短押しと、画面 ON OR 画面 OFF

メニュー画面で短押しと、待受画面に戻ります

USB インターフェース：充電 OR データ転送

タッチパネル：全ての機能がタッチパネルで実現できます

ウォッチ起動 電源ボタンを押すと、待受画面になります。

さらに電源ボタンを2回押しと文字盤画面になります。

長押しで文字盤画面と待受画面の切り替えができます。

上から下へスライドすると、Bluetooth と機内モードの設定ができます。

明るさ調節：画面を左右にスライドしてホーム画面に入る。ホーム画面を左右にスライドすることでメニューを切り替えることができます。

スタイル表示設定 3.1 ウォッチフェイスの設定

ウォッチフェイスの設定画面に入るには、待機画面状態で電源キーを2回短押しする。

タッチスクリーンが消灯しているときに、電源キーで点灯させる。

ウォッチフェイスを変更するには、表示したい画面をタッチしてください。

3.2 テーマの変更---変更方法：(1) 電源をオンにしてメニュー画面に入る。右図のアイコン（テーマ選択）を選択する。-表示したいテーマを選択してください。

(2) 電源をオンにしてメニュー画面に入る。右図のアイコン（ツール）を選択する。

-ツール-表示-テーマ-システム-静止テーマ

表示したいテーマを選択してください。

SmartWatch 対応のアプリケーション

アプリをダウンロードする

お先に下記のQRコードを読み込んでください。

QRコードをスキャンしたらダウンロードを開始します。

QRコード ご注意：本アプリケーションはAndroid 端末（データ転送、Bluetooth 接続等）のみ対応しています。

アプリケーションは随時更新を行い、最新バージョンをお使いになることをおすすめします。

2.接続する、使用アプリ---アプリケーションのインストールについて (Android)

Android スマホ、指示に従って操作し、セットアップを行う。

2.2 Android app (セットアップ後)

アプリを開き、画面に表示される内容を、「同意する」をタップする、

アプリを開きます。 アプリを選択し、スマートフォンのBluetooth 機能をオンにします。

(オフすると、繋げなくなるので、Bluetooth をオフしないでください)

3.Bluetooth&データ同期

3.1 スマホとの接続

機器のBluetooth 機能がオンになっていない場合は、画面に表示される「Bluetooth:ON」

をタップしてください

スマホから接続する場合：

1. 使用アプリを開き、Bluetooth ボタンを押してください
2. メニュー内のペアリングを選択してください。
3. 接続完了してから日付、時間の同期を行ってください。

本体から接続する場合:

1. Bluetooth メニューを開き、Bluetooth 検索ボタンを押してください
2. スマホ画面のペアリングを選択してください。
3. スマートウォッチ画面内の「yes」ボタンを押してください。
- 3.2 データ同期 接続完了してから、本体の画面に表示される「データ同期」をタップしてください。
- 4.1 通話 電話番号を入力し、bluetooth 電話をしてください
- 4.2 メッセージ データ同期してから、bluetooth でスマホのメッセージが送信可能。
- 4.3 通話記録 機能メニューから通話記録がチェック可能。
- 4.4 電話帳 スマホ内の電話番号を同期してください
- 4.5 Bluetooth bluetooth 名、IP アドレスがチェック可能。
- 4.8 リモートカメラ スマートウォッチでスマホをリモートして撮影ができる
- 4.9 音楽 Bluetooth4.1 対応可能
- 4.10 設定 スマートウォッチで時間、テーマ、言語、ハンド操作、リセットができる。
- 4.11 歩数計 タッチして歩数計測が開始する。歩行時に腕を振ることで消耗されたカロリー、スピード、歩行距離等のカウントが開始される。
ただし、腕を振らないと、正確にカウントされない場合がございますので、あくまでも目安としてご利用ください。
ご注意: 計測中、メニュー画面を戻り歩数計測を続けたい場合は、電源キーだけを押してください。
- 4.12 睡眠モニター 睡眠モニター機能で睡眠を検知し、睡眠時間を計測できる。睡眠中、スクリーンをメニュー画面に戻ってください。また、計測中、睡眠モニター機能の中止をお避けください
- 4.13 座りがち注意 座り過ぎ注意機能で長時間座り続けると運動するよう注意喚起をしてくれる。せめて1時間に10分間の運動がおすすめ。

備考: 歩数計、睡眠モニター、座りがち注意という機能は同時にオンにできません。

一つの機能をオンにしたいなら、他の機能をオフしなければならない。

三、注意事項

1. ご使用する前にまずフル充電してください。
2. 充電する際は付属したケーブルと充電器を使用してください。
3. ペアリング中は接続切れる場合は、接続が直る前は紛失防止モードを使えないのでご注意ください。
4. ペアリング中は希に接続が切れる場合がございますので、手動でもう一度ペアリングを行ってください。(2分以内は自動的に再ペアリングを行う) ペアリング時は設備の時間と日付を同期してください。同期しない場合は、通話履歴の表示ができないのでご注意ください。
5. ミュージックモード中はAndroidでは希に曲のタイトルが表示されない場合がございますが、仕様なのでご安心ください。

よくある質問

使用中で問題が起きる場合はまず本項目を読んでください。

1. 電源が入らない--電源ボタンを押す時間が短いすぎるかももう一度3秒以上押してください。
また、バッテリーが切れた可能性もあるため、充電も試してください。
自動にシャットダウン--バッテリー残量不足か充電を試してください。
使用時間が短いすぎる--フル充電していない可能性がございます(2時間以上の充電を確保してください)
何年か使用された場合はバッテリーの劣化なども原因になります。
着信があるとき、相手の名前が表示されない--ペアリング時は連絡先を登録しなかったか同期しなかった可能性がございます。
もう一度連絡先を同期してください。
通話音質が悪い--携帯とウォッチの距離が離れ過ぎたか、両者の距離を調整してみてください。

Smart Watch

User Manual

Please read the manual before use.

1. Safety Warning

◆ The information in this document won't be modified or extended in accordance with any notice.

◆ The watch should be charging 2 hours at least before use

Security Code

◆ The original code is 1122. This code can prevent your watch in use by others without your permission.

◆ Please change the original code to insure your personal information safe.

2. Product details:

2.1 Product details

Power button: Long press to power On/Off; Short press to awake/dark screen/ Back to main menu

USB port: Charging/Data:

Touch screen: each function(main menu) will be shown and displayed on capacitive touch screen.

2.2 Products quick into

You can enter into next page by sliding screen to the left, and return to last page by sliding screen right; It is will be in mistake for a click if the drag distance too short.

2.3 Clock Display (the following picture is for reference only, goods in kind prevail)

Setting method:

Method 1: Power on , when the phone in clock mode, please click middle screen and set different clock interfaces if you like.

Method 2: Power on, Main menu: setting—phone setting—standby menu display—Wallpaper display.

3. Product quick use

3.1 Download the Sync software.

Scan QR code, down load the APP which can match your android phone, This APP only use for the Sync between watch and phone, will not take your phone GPRS.

If you already download the related softwares, please check the version and use the newest related in order to ensure all function normal use. Please update the software when it has new one.

3.2 Install and use the Sync software

Android Application installation:

Please install the android application in your smart phone, You can storage it into your phone memory or install by Sync assistant.

Android application usage (already installed)

(Smart phone) Setting—Accessibility—Enter into Bluetooth notice (service), enabled this service. (Please choose "sure" when shown a warning notices) the application runs on the background automatically and sync function will be switched on as below:

Click the Bluetooth notices and choose the Notification service, select your Personal or System application in Notify application.

Telephone service is including SMS, incoming call and seek watch.

Notice:

Please don't shut the Bluetooth notify service when you are clearing software by background or close background application software. It will affect the Sync function between watch and phone if shut it.

3.3 Bluetooth Connection and Sync function

3.3.1 From phone to watch

Phone setting—turn on the Bluetooth—search for devices, please click pair devices when found it. And also choose "yes" in your mobile phone, paired done.

Please choose "sure" when there is phone book request. Meanwhile you'd better choose "no remind again", this is convenience when you connect next time (without remind again).

Notice: the Sync software can open in sync APP already installed and Accessibility, the mobile will show Bluetooth connected done after 2-5 min; the watch will inform you the time of Sync with phone, than the Sync switched on. The message will sync to you watch when it incoming to mobile.

3.3.2 From watch to phone

BT dialer on Smart watch --Search new device—found your smart watch (such as s9500)—connect.The processes of next are same with 3.3.1

3.4 Base function

3.4.1 Message

Sync phone or watch message.

3.4.2 Bluetooth

Sets the Bluetooth status, turn on/off.

3.4.3 Calls records

You can check your phone call records after you connect with the Bluetooth.

Shown all records including miss call, dialed calls and receive call; You can check the date, time and phone number of the miss call after you choose it. But only can call this number.

3.4.4 BT dialer

Paired devices from smart watch

3.4.5 remote notifier (Only for Android users)

When there is SMS, incoming messages from QQ and other applications on the connected phone, the watch phone will alert you to read them.

3.4.6 Remote cameras

smart watch camera can control smart phone camera.

3.4.7 Anti lost

Watch seek phone, or phone seek watch.

3.4.8 Setting

Notice: sets clocks display and theme in phone setting. In the security Settings. The safe code is 1122.

3.4.9 Padometer

It can be adopted as a tool to avoid insufficient or excessive exercise by measuring calorier or calories consumption based on collected data, such as number of steps, distance, speed time, etc. to control exercise.

If you want return to main menu but keep pedometer during the exercise. Please press the power button.

3.4.10 Sleep monitor

Show your sleep quality base on your sleep times.

3.4.11 Sedentary remind

You can set a time to remind you up to do some exercise, we suggest you this time could be one hours.

3.4.12 Quick response

It can download sync software when scan the quick response, if there is a new version need to update, please contact with our servicer, our company will provide a new link for your download.

3.4.13 Alarm

3.4.14 Calendar

3.4.15 Calculator

3.4.16 Profiles

3.4.17 File manager

3.4.18 Audio player

Can play music from local or smart phone after connect with Bluetooth.

3.4.19 Camera

3.4.20 pictures

3.4.21 Recorder

3.4.22 QQ:need to insert SIM card first,and SIM card have GPRS.

3.4.23 Browser

Browser need your phone has SIM card and can surf the Internet.

4. Notice

Main menu: Theme setting, choose the theme if you like.

4.1 Full charge before use, the charge time need 1-2 hours.

4.2 Use the accessories cable and charger, or your android phone accessories.

4.3 Bluetooth will disconnect when exceed the distances, after switch on the Anti lost. The smart search function can't be use before reconnect with Bluetooth.

4.4 Please reconnect with BT if it's disconnected occasionally (please Manual connect if the Bluetooth disconnect over 5 minutes). Please agree the phone book Sync otherwise there is no called phone book.

4.5 When playing the music, some of music's name can shown and some can't, it is normal. Because android phone are difference.

5. Common trouble shooting

Please refer below key function for any problems with the watch, if the problem is still unsolved, please contact with your dealer or serviceman appointed.

5.1 Unable to switch on

The time of press the power button too short, please keep it more than 3 seconds

Low power, please charge it.

5.2 Shut down automaticly

Low power, please charge it.

5.3 Using time too short.

Battery is not full, please make sure it is full power (full charge need 2 hours at least).

During the use of SIM card, the power will be run off soon if the signal too poor.

5.4 Unable to charge.

The battery's life will be reduce after few years, please check if the battery are work.

Change a new charger if it is unworkable.

Please check the USB slot connecting good, if no, please try again.

5.5 No caller's name when incoming call

Forgot to choose upload the phone book when connected with BT, or unselected keep upload the phone book.

Forgot to sync the phone book when reconnected, please pair the device and connect BT again.

5.6 Bad phone call voice

Watch and phone are separated too far, please be more close; Bad signal of BT.

Bad signal of your own phone call place, please change a more better place for phone call.

保 修 卡			
客户资料			
型号	售机单位	(签章)	
客户姓名	联系电话		
销售电话	购买日期		
产品IMEI号			
客户地址			
销售地址			
摘 要			
日期	故障现象	检修	备注